


FLOOR PLAN



WHAT ROOM NUMBERS MEAN FIRST DIGIT IS THE FLOOR. SECOND IS THE CORRIDOR. LAST TWO DIGITS ARE THE ROOM.

CORRIDOR INDICATOR

FOURTH, FIFTH & SIXTH FLOORS
 Note: Change first digit to 5 and 6 to indicate fifth and sixth floors.